



## SRAM vs DRAM Summary

	Tran. per bit	Access time	Persist?	Sensitive?	Cost	Applications
SRAM	6	1X	Yes	No	100x	cache memories
DRAM	1	10X	No	Yes	1X	Main memories, frame buffers


Page 1





## **Conventional DRAM Organization**


• d x w DRAM:





6


## Reading DRAM Supercell (2,1)

- Step 2(a): Column access strobe (CAS) selects column 1.
- Step 2(b): Supercell (2,1) copied from buffer to data lines, and eventually back to the CPU.











## Typical Bus Structure Connecting CPU and Memory


- A bus is a collection of parallel wires that carry address, data, and control signals
- · Buses are typically shared by multiple devices






## Memory Read Transaction (3)


• CPU reads word x from the bus and copies it into register %eax.





## Memory Read Transaction (2)

 Main memory reads A from the memory bus, retrieves word x, and places it on the bus.












## Memory Write Transaction (3)


• Main memory reads data word y from the bus and stores it at address A.








**Recording zones** 



22




 Modern disks partition tracks into disjoint subsets called recording zones


> Each track in a zone has the same number of sectors, determined by the circumference of innermost track.


 Each zone has a different number of sectors/track, outer zones have more sectors/track than inner zones.


 So we use average number of sectors/track when computing capacity.





## Disk Operation (Multi-Platter View)

















Page 8






Disk Access – Read  $\overbrace{fiter BLUE}_{read} \qquad \overbrace{fiter REU}_{read} \qquad \overbrace{fiter REU}_{read} \qquad \overbrace{fiter RED}_{read} \qquad \overbrace{fiter RED}_{read} \qquad \sub{fiter RED}_{read} \qquad$ 



Page 9



# Logical Disk Blocks Modern disks present a simpler abstract view of the complex sector geometry: The set of available sectors is modeled as a sequence of b-sized logical blocks (0, 1, 2, ...) Mapping between logical blocks and actual (physical) sectors Maintained by hardware/firmware device called disk controller. Converts requests for logical blocks into (surface,track,sector) triples. Allows controller to set aside spare cylinders for each zone. Accounts for the difference in "formatted capacity" and "maximum capacity".

## **Disk Access Time Example**

- · Given:
  - Rotational rate = 7,200 RPM
  - Average seek time = 9 ms.
  - Avg # sectors/track = 400.
- Derived:
  - Tavg rotation =  $1/2 \times (60 \text{ secs}/7200 \text{ RPM}) \times 1000 \text{ ms/sec} = 4 \text{ ms}.$
  - Tavg transfer = 60/7200 RPM x 1/400 secs/track x 1000 ms/sec = 0.02 ms
  - Taccess = 9 ms + 4 ms + 0.02 ms
- Important points:
  - Access time dominated by seek time and rotational latency.
  - First bit in a sector is the most expensive, the rest are free.
  - SRAM access time is about 4 ns/doubleword, DRAM about 60 ns
    - Disk is about 40,000 times slower than SRAM,
    - 2,500 times slower then DRAM.


38

## **Disk Access Time Example**


- Given:
  - Rotational rate = 7,200 RPM
  - Average seek time = 9 ms.
  - Avg # sectors/track = 400.
- Derived:
  - Tavg rotation =  $1/2 \times (60 \text{ secs}/7200 \text{ RPM}) \times 1000 \text{ ms/sec} = 4 \text{ ms}.$
  - Tavg transfer = 60/7200 RPM x 1/400 secs/track x 1000 ms/sec = 0.02 ms
  - Taccess = 9 ms + 4 ms + 0.02 ms
- Important points:
  - Access time dominated by seek time and rotational latency.
  - First bit in a sector is the most expensive, the rest are free.
  - SRAM access time is about 4 ns/doubleword, DRAM about 60 ns
    - · Disk is about 40,000 times slower than SRAM,
    - 2,500 times slower then DRAM.





• Consider a magnetic disk with 1000 cylinders rotating at a speed of 7200 revolutions per minute. The sector size on the disk is 1024 bytes. Requests for sectors arriving from the file system can be located anywhere on thedisk with equal probability and the locations of the requested sectors are independent of each other. Under these assumptions, the average seek time is 7 milliseconds. The transfer time per sector is 0.01 milliseconds (i.e., the raw data rate is 100 Megabytes per second). What is the effective data rate?





41

















Sequential read thput	550 MB/s	Sequential write thput	470 MB/s
Random read thput	365 MB/s	Random write thput	303 MB/s
Avg seq read time	50 us	Avg seq write time	60 us

- · Sequential access faster than random access
  - Common theme in the memory hierarchy
- · Random writes are somewhat slower
  - Erasing a block takes a long time (~1 ms)
  - Modifying a block page requires all other pages to be copied to new block
  - In earlier SSDs, the read/write gap was much larger.


Source: Intel SSD 730 product specification.

49




## SSD Tradeoffs vs Rotating Disks

- Advantages
  - No moving parts → faster, less power, more rugged
- Disadvantages
  - Have the potential to wear out
    - Mitigated by "wear leveling logic" in flash translation layer
    - E.g. Intel SSD 730 guarantees 128 petabyte (128 x 10<sup>15</sup> bytes) of writes before they wear out
- Applications
  - MP3 players, smart phones, laptops
  - Also becoming prevalent in desktops and servers



## Coming Up: Virtual Memory

## A System Using Physical Addressing



 Used in "simple" systems like embedded microcontrollers in devices like cars, elevators, and digital picture frames

55

